



Emergency Shower Monitor ESM-200

The PC Board for this ESM-200 has been shipped in a separate protective wrapping. The PC Board should be installed after all wall finishes are completed to prevent any damage during the construction process. To install this board onto the track, position one side of the board into the groove of the track and press down firmly until the opposite side snaps into place. Refer to the image below for wire placement

